



# Network Monitoring and Management

## Cisco Configuration



These materials are licensed under the Creative Commons *Attribution-Noncommercial 3.0 Unported* license (<http://creativecommons.org/licenses/by-nc/3.0/>) as part of the ICANN, ISOC and NSRC Registry Operations Curriculum.

# Topics

- CLI modes
- Accessing the configuration
- Basic configuration (hostname and DNS)
- Authentication and authorization (AAA)
- Log collection
- Time Synchronization (date/timezone)
- SNMP configuration
- Cisco Discovery Protocol (CDP)

# CLI Modes

## User EXEC

- Limited access to the router
- Can show some information but cannot view nor change configuration

rtr>

## Privileged EXEC

- Full view of the router's status, troubleshooting, manipulate config, etc.

rtr> enable

rtr#

# We show the details, do them later

*This presentation contains detailed steps to explain base concepts. You will do these steps this week. Here we show them quickly as an introduction.*

# Accessing the router

Before setting up SSH

- telnet 10.10.x.254
- login “cisco” and “cisco” (user and password)

Privileged user can go to privileged mode:

- rtr> enable (default password is “cisco”)
- rtr# configure terminal
- rtr(config)#

Type in configuration commands

Exit and save the new configuration

- rtr(config)# end
- rtr# write memory

# Accessing the configuration

**There are two configurations:**

- Running config is the actual configuration that is active on the router and stored in RAM (will be gone if router is rebooted):

```
rtr# configure terminal          (conf t)
```

```
rtr(config)# end
```

```
rtr# show running-config        (show run)
```

- Startup config

Stored in NVRAM (Non-Volatile RAM):

```
rtr# copy running-config startup-config    (or)
```

```
rtr# write memory              (wr mem)
```

```
rtr# show startup-config       (sh start)
```

# Basic configuration (hostname and DNS)

- Assign a name

```
rtr(config)# hostname rtrX
```

- Assign a domain

```
rtr(config)# ip domain-name ws.nsrc.org
```

- Assign a DNS server

```
rtr(config)# ip name-server 10.10.0.241
```

- Or, disable DNS resolution

```
rtr(config)# no ip domain-lookup
```

if no dns this is *very useful* to avoid long waits

# Authentication and authorization

Configure passwords in the most secure manner.

- Use the improved method which uses hash function

Example:

```
# enable secret 0 cisco  
# user admin secret 0 cisco
```

# Authentication and authorization

Configuring SSH with a 2048 bit key (at least 768 for OpenSSH clients)

```
rtr(config)# aaa new-model  
rtr(config)# crypto key generate rsa (key size prompt)
```

Verify key creation:

```
rtr# show crypto key mypubkey rsa
```

Optionally register events. Restrict to only use SSH version 2 :

```
rtr(config)# ip ssh logging events  
rtr(config)# ip ssh version 2
```

Use SSH, disable *telnet* (only use telnet if no other option)

```
rtr(config)# line vty 0 4  
rtr(config)# transport input ssh
```

Note: on CatOS, you'll need to explicitly disable telnet

# Log collection (syslog\*)

Send logs to the *syslog* server:

```
rtr(config)# logging 10.10.x.x
```

Identify what channel will be used (local0 to local7):

```
rtr(config)# logging facility local5
```

Up to what priority level do you wish to record?

```
rtr(config)# logging trap <logging_level>
```

| <0-7>         | Logging severity level            |              |
|---------------|-----------------------------------|--------------|
| emergencies   | System is unusable                | (severity=0) |
| alerts        | Immediate action needed           | (severity=1) |
| critical      | Critical conditions               | (severity=2) |
| errors        | Error conditions                  | (severity=3) |
| warnings      | Warning conditions                | (severity=4) |
| notifications | Normal but significant conditions | (severity=5) |
| informational | Informational messages            | (severity=6) |
| debugging     | Debugging messages                | (severity=7) |

# Time synchronization

**It is essential that all devices in our network are time-synchronized**

**In config mode:**

```
rtr(config)# ntp server pool.ntp.org  
rtr(config)# clock timezone <timezone>
```

To use UTC time

```
rtr(config)# no clock timezone
```

**If your site observes daylight savings time you can do:**

```
rtr(config)# clock summer-time recurring last Sun Mar 2:00 last Sun Oct 3:00
```

**Verify**

```
rtr# show clock  
22:30:27.598 UTC Tue Feb 15 2011  
rtr# show ntp status  
Clock is synchronized, stratum 3, reference is 4.79.132.217  
nominal freq is 250.0000 Hz, actual freq is 249.9999 Hz, precision is 2**18  
reference time is D002CE85.D35E87B9 (11:21:09.825 CMT Tue Aug 3 2010)  
clock offset is 2.5939 msec, root delay is 109.73 msec  
root dispersion is 39.40 msec, peer dispersion is 2.20 msec
```

# SNMP configuration

## Start with SNMP version 2

- It's easier to configure and understand
- Example:

```
rtr(config)# snmp-server community NetManage ro 99  
rtr(config)# access-list 99 permit 10.10.0.0 0.0.255.255
```

# SNMP configuration

From a Linux machine (once snmp utils are installed), try:

```
snmpwalk -v2c -c NetManage 10.10.x.254 sysDescr
```

# Cisco Discovery Protocol (CDP)

Enabled by default in most modern routers

If it's not enabled:

```
Rtr(config) # cdp enable
```

```
Rtr(config) # cdp run
```

(in older CISCO IOS  
versions)

To see existing neighbors:

```
rtr# show cdp neighbors
```

Tools to visualize/view CDP announcements:

*tcpdump*

*cdpr*

*wireshark*

*tshark*

# Enabling NetFlow (traffic flow export)

Configure FastEthernet 0/0 to generate netflow and export flows to 10.10.0.250 on port 9996:

```
rtr# configure terminal  
rtr(config)# interface FastEthernet 0/0  
rtr(config-if)# ip flow ingress  
rtr(config-if)# ip flow egress  
rtr(config-if)# exit  
rtr(config-if)# ip flow-export destination 10.10.0.250 9996  
rtr(config-if)# ip flow-export version 5  
rtr(config-if)# ip flow-cache timeout active 5
```

This breaks up long-lived flows into 5-minute fragments. You can choose any number of minutes between 1 and 60. If you leave it at the default of 30 minutes your traffic reports will have spikes.

# Enabling NetFlow cont.

```
rtr(config)# snmp-server ifindex persist
```

This enables ifIndex persistence globally. This ensures that the ifIndex values are persisted during router reboots.

Now configure how you want the ip flow top-talkers to work:

```
rtr(config)#ip flow-top-talkers
rtr(config-flow-top-talkers)#top 20
rtr(config-flow-top-talkers)#sort-by bytes
rtr(config-flow-top-talkers)#end
```

Now we'll verify what we've done

```
rtr# show ip flow export
rt# show ip cache flow
```

See your "top talkers" across your router interfaces

```
rtr# show ip flow top-talkers
```

# Questions?

?

For more information, check out

[http://www.cisco.com/en/US/docs/ios/12\\_2/configfun/configuration/guide/ffun\\_c.html](http://www.cisco.com/en/US/docs/ios/12_2/configfun/configuration/guide/ffun_c.html)