

Interoperating with Cisco Switches

Version: 1.00

Published: Mar 19, 2010

D-Link HQ

Scope

This guide is a one-stop resource to help users set up their network quickly and optimize the features of D-Link and vendors' equipment smoothly. This guide focuses on the configuration of D-Link and Cisco switches and includes topology examples for setting up a multi-vendor environment.

Use this document to learn, use and configure the different features of D-Link and Cisco management switches.

Audience

This document is written for system administrators, network managers and IT personnel who are responsible for the deployment of management switches.

About This Guide

This guide is structured into four parts as follows:

Title	Description
Terminology	Detailed descriptions of functions that are used to explain similar concepts on both D-Link & Cisco platforms.
Topology	Topology examples to show the interoperability of D-Link and Cisco switches.
Configuration	Step-by-step instructions on how to configure and set up the devices.
Troubleshooting Tips	Command examples on how to quickly troubleshoot and configure if interoperation fails.

For more Information

This guide is applicable to all D-Link Managed Switches (DES-3000 series and above). Please refer to D-Link Managed Switch User Manual or CLI Manual for more detailed explanations or parameter descriptions.

Table of Contents

VLAN CONFIGURATION	3
Terminology	3
Topology	3
Configuration	4
Link Aggregation	11
Terminology	11
Compatibility between D-Link Port-Trunking and Cisco Port-Channel	11
Topology	12
Configuration	12
Troubleshooting Examples	13
Spanning Tree Configuration	20
Terminology	20
Topology	20
Configuration	20
Troubleshooting Examples	21
Multiple Spanning Tree Configuration	25
Terminology	25
Compatibility between MSTOP and PVST	25
Topology	25
Configuration	26
Troubleshooting Examples	27
Open Shortest Path Fast (OSPF) Configuration	33
Terminology	33
Topology – Single OSPF Area	33
Configuration	33
Troubleshooting Examples	36
Topology – Single OSPF Area	41
Configuration	41
Troubleshooting Examples	44

VLAN CONFIGURATION

This chapter introduces port-based VLANs that D-Link and Cisco switches support.

Terminology

Cisco	D-Link	Description
Trunking Port	Tagged Port	This port carries multiple 802.1Q tagged VLANs that are usually used for uplink and IP phone ports
Access Port	Untagged Port	A port which is an untagged member of a VLAN.
Native VLAN	Untagged Membership of Physical Ports	In Cisco LAN switch environments the native VLAN is typically untagged on VLAN trunk ports. Native VLAN is not associated to any tag on an 802.1Q link and is used for all the untagged traffic received on an 802.1Q port. By default, all VLAN membership of D-Link switches and access VLAN in Cisco switches is VLAN 1.

Topology




Figure-1 Port-based VLAN Configuration

Configuration

VLAN Configuration on a Cisco Switch

The following section lists step-by-step instructions for configuring VLAN and IP on D-Link and Cisco management switches.

	Command Example	Purpose
Step 1	<pre>Catalyst# config terminal Catalyst(config)# vlan 10,20,30 Catalyst(config-vlan)# exit</pre>	To create VLAN interfaces for ports 10, 20 and 30.
Step 2	<pre>Catalyst(config)# interface range gigabitEthernet 1/0/1-6 Catalyst(config-if)# switchport mode access Catalyst(config-if)# switchport access vlan 10 Catalyst(config-if)# exit Catalyst(config)# interface range gigabitEthernet 1/0/7-12 Catalyst(config-if)# switchport mode access Catalyst(config-if)# switchport access vlan 20 Catalyst(config-if)# exit Catalyst(config)# interface range gigabitEthernet 1/0/13-18 Catalyst(config-if)# switchport mode access Catalyst(config-if)# switchport access vlan 30 Catalyst(config-if)# exit</pre>	To change ports to access mode and assign membership for each VLAN.
Step 3	<pre>Catalyst(config)# interface gigabitEthernet 1/0/21 Catalyst(config-if)# switchport trunk encapsulation dot1q Catalyst(config-if)# switchport trunk allowed vlan 1,10,20,30 Catalyst(config-if)# switchport mode trunk Catalyst(config-if)# exit</pre>	To create a VLAN trunking port.



Note: By default a Cisco VLAN trunk sends to and receives traffic from all VLANs. To restrict the traffic a VLAN trunk carries, remove VLAN-list parameter to remove specific VLANs from the allowed list.



Note: By default, all ports of a Cisco switch belong to VLAN 1, access mode.

IP Configuration on a Cisco Switch

The following configuration example is for L3 switches. For layer 3 switches, an IP address has to be defined for each VLAN and for a layer 2 switch, an IP address can only be configured on one VLAN for management purposes.

	Command Example	Purpose
Step 1	<pre>Catalyst(config)# interface vlan 1 Catalyst(config-vlan)# ip address 192.168.0.1 255.255.255.0 Catalyst(config-vlan)# no shutdown</pre>	To configure the IP addresses for the

<pre> Catalyst(config-vlan)# exit Catalyst(config)# interface vlan 10 Catalyst(config-vlan)# ip address 192.168.10.1 255.255.255.0 Catalyst(config-vlan)# no shutdown Catalyst(config-vlan)# exit Catalyst(config)# interface vlan 20 Catalyst(config-vlan)# ip address 192.168.20.1 255.255.255.0 Catalyst(config-vlan)# no shutdown Catalyst(config-vlan)# exit Catalyst(config)# interface vlan 30 Catalyst(config-vlan)# ip address 192.168.30.1 255.255.255.0 Catalyst(config-vlan)# no shutdown Catalyst(config-vlan)# exit </pre>	VLAN interfaces.
---	------------------

VLAN Configuration on a D-Link Switch

In this example, ports 1 to 18 are removed from VLAN 1 (default VLAN) and are assigned to three different VLANs. Here are the details:

- Ports 1 to 6 are assigned to VLAN 10.
- Ports 7 to 12 are assigned to VLAN 20.
- Ports 13 to 18 are assigned to VLAN 30.
- Port 21 (uplink) is tagged with VLAN 10, 20, 30 and belongs to an untagged member of VLAN 1.

	Command Example	Purpose
Step 1	<pre> switch# create vlan 10 tag 10 switch# create vlan 20 tag 20 switch# create vlan 30 tag 30 switch# config vlan default delete 1-18 switch# config vlan 10 add untagged 1-6 switch# config vlan 20 add untagged 7-12 switch# config vlan 30 add untagged 13-18 switch# config vlan 10 add tagged 21 switch# config vlan 20 add tagged 21 switch# config vlan 30 add tagged 21 </pre>	To create VLAN interfaces for ports 10, 20, 30 and assign port membership.

IP Configuration on a D-Link Switch

The following configuration example is for L3 switches.

Layer 3 switches require an IP address for each VLAN; Layer 2 switches only require a system IP address.

	Command Example	Purpose
Step 1	<pre>switch# config ipif System ipaddress 192.168.0.2/24 switch# create ipif 10 192.168.10.2/24 10 switch# create ipif 20 192.168.20.2/24 20 switch# create ipif 30 192.168.30.2/24 30</pre>	To configure the IP addresses for the VLAN interfaces.

Troubleshooting Examples

The following section lists command examples for verifying VLANs and port assignments on D-Link and Cisco switches.

Verifying VLANs and Ports Assignments on a Cisco Switch

The following example shows you how to verify the member ports and all the VLAN interfaces.

Command Example			
Catalyst# show vlan			
VLAN	Name	Status	Ports
1	default	active	Gi1/0/19, Gi1/0/20, Gi1/0/21, Gi1/0/22, Gi1/0/23, Gi1/0/24
10	VLAN0010	active	Gi1/0/1, Gi1/0/2, Gi1/0/3, Gi1/0/4, Gi1/0/5, Gi1/0/6
20	VLAN0020	active	Gi1/0/7, Gi1/0/8, Gi1/0/9, Gi1/0/10, Gi1/0/11, Gi1/0/12
30	VLAN0030	active	Gi1/0/13, Gi1/0/14, Gi1/0/15, Gi1/0/16, Gi1/0/17, Gi1/0/18

The following example shows you how to set a trunking port.

Command Example
<pre>Catalyst# show interfaces gigabitEthernet 1/0/21 switchport Name: Gi1/0/19 Switchport: Enabled Administrative Mode: trunk Operational Mode: trunk Administrative Trunking Encapsulation: dot1q Operational Trunking Encapsulation: dot1q Negotiation of Trunking: On Access Mode VLAN: 1 (default) Trunking Native Mode VLAN: 1 (default) Administrative Native VLAN tagging: enabled Voice VLAN: none Administrative private-vlan host-association: none Administrative private-vlan mapping: none Administrative private-vlan trunk native VLAN: none Administrative private-vlan trunk Native VLAN tagging: enabled</pre>

```

Administrative private-vlan trunk encapsulation: dot1q
Administrative private-vlan trunk normal VLANs: none
Administrative private-vlan trunk associations: none
Administrative private-vlan trunk mappings: none
Operational private-vlan: none
Trunking VLANs Enabled: 1,10,20,30
Pruning VLANs Enabled: 2-1001
Capture Mode Disabled
Capture VLANs Allowed: ALL

Protected: false
Unknown unicast blocked: disabled
Unknown multicast blocked: disabled
Appliance trust: none

```

The following example shows you how to set the access ports.

Command Example

```

Catalyst# show interfaces gigabitEthernet 1/0/1 switchport
Name: Gi1/0/1
Switchport: Enabled
Administrative Mode: static access
Operational Mode: down
Administrative Trunking Encapsulation: negotiate
Negotiation of Trunking: Off
Access Mode VLAN: 10 (VLAN0010)
Trunking Native Mode VLAN: 1 (default)
Administrative Native VLAN tagging: enabled
Voice VLAN: none
Administrative private-vlan host-association: none
Administrative private-vlan mapping: none
Administrative private-vlan trunk native VLAN: none
Administrative private-vlan trunk Native VLAN tagging: enabled
Administrative private-vlan trunk encapsulation: dot1q
Administrative private-vlan trunk normal VLANs: none
Administrative private-vlan trunk associations: none
Administrative private-vlan trunk mappings: none
Operational private-vlan: none
Trunking VLANs Enabled: ALL
Pruning VLANs Enabled: 2-1001
Capture Mode Disabled
Capture VLANs Allowed: ALL

Protected: false
Unknown unicast blocked: disabled
Unknown multicast blocked: disabled
Appliance trust: none

```

The following example shows you how to verify the IP address of each VLAN interface.

Command Example

Catalyst# **show ip interface brief**

Interface	IP-Address	OK?	Method	Status	Protocol
Vlan1	192.168.0.1	YES	manual	up	up
Vlan10	192.168.10.1	YES	manual	up	up
Vlan20	192.168.20.1	YES	manual	up	up
Vlan30	192.168.30.1	YES	manual	up	up

Verifying VLANs and Port Assignments on D-Link Switches

The following example shows you how to verify all the VLAN interfaces and member ports.

Command Example

switch# **show vlan**

Command: show vlan

VID	: 1	VLAN Name	: default
VLAN Type	: Static	Advertisement	: Enabled
Member Ports	: 19-24		
Static Ports	: 19-24		
Current Tagged Ports	:		
Current Untagged Ports	: 19-24		
Static Tagged Ports	:		
Static Untagged Ports	: 19-24		
Forbidden Ports	:		
Status	: Active		
VID	: 10	VLAN Name	: 10
VLAN Type	: Static	Advertisement	: Disabled
Member Ports	: 1-6, 21		
Static Ports	: 1-6, 21		
Current Tagged Ports	: 21		
Current Untagged Ports	: 1-6		
Static Tagged Ports	: 21		
Static Untagged Ports	: 1-6		
Forbidden Ports	:		
Status	: Active		
VID	: 20	VLAN Name	: 20
VLAN Type	: Static	Advertisement	:
Disabled			
Member Ports	: 7-12, 21		
Static Ports	: 7-12, 21		

```

Current Tagged Ports      : 21
Current Untagged Ports    : 7-12
Static Tagged Ports       : 21
Static Untagged Ports     : 7-12
Forbidden Ports           :
Status                    : Active

VID                        : 30                      VLAN Name :30
VLAN Type                  : Static                  Advertisement :Disabled
Member Ports               : 13-18,21
Static Ports               : 13-18,21
Current Tagged Ports       : 21
Current Untagged Ports     : 13-18
Static Tagged Ports        : 21
Static Untagged Ports      : 13-18
Forbidden Ports            :
Status                     : Active

Total Entries: 4

```

The following example shows you how to verify the IP address of each VLAN interface.

Command Example

```

switch# show ipif
Command: show ipif

```

```

IP Interface              : 10
VLAN Name                  : 10
Interface Admin state     : Enabled
DHCPv6 Client State       : Disabled
IPv4 Address               : 192.168.10.2/24 (Manual) Primary
Proxy ARP                  : Disabled (Local : Disabled)
IP Directed Broadcast      : Disabled
IP MTU                     : 1500

IP Interface              : 20
VLAN Name                  : 20
Interface Admin state     : Enabled
DHCPv6 Client State       : Disabled
IPv4 Address               : 192.168.20.2/24 (Manual) Primary
Proxy ARP                  : Disabled (Local : Disabled)
IP Directed Broadcast      : Disabled
IP MTU                     : 1500

IP Interface              : 30
VLAN Name                  : 30
Interface Admin state     : Enabled

```

```
DHCPv6 Client State      : Disabled
IPv4 Address             : 192.168.30.2/24 (Manual) Primary
Proxy ARP                : Disabled (Local : Disabled)
IP Directed Broadcast    : Disabled
IP MTU                   : 1500

IP Interface             : System
VLAN Name                : default
Interface Admin state    : Enabled
DHCPv6 Client State      : Disabled
IPv4 Address             : 192.168.0.2/24 (Manual) Primary
Proxy ARP                : Disabled (Local : Disabled)
IP Directed Broadcast    : Disabled
IP MTU                   : 1500

Total Entries: 4
```

Link Aggregation

This chapter introduces Link Aggregation Control Protocol (LACP) function that both D-Link and Cisco switches support.

Terminology

Cisco	D-Link	Description
Channel-group ID	Group ID	ID of a port aggregation group.
Port-channel	Link Aggregation Group	A logical port aggregation group.

Link Aggregation Group

Cisco defines the Aggregation group as **Port-channel** and is configured as the **Interface Port-channel x**. The default **Port-channel** mode is static trunk, and the LACP mode for a dynamic trunk. On the other hand, D-Link calls it **Link Aggregation Group** and is configured as type static for a static trunk or type LACP for a dynamic trunk.

Static and Dynamic Trunks/Channels

In between two switches, a **Static Trunk** becomes an active trunk unconditionally and independently of the other switch's configuration. A static trunk does not require any protocols.

A **Dynamic Trunk** is active only when it is enabled in both D-Link and Cisco switches. To do so, the switches exchange messages, either through Port Aggregation Protocol (PAgP) or Link Aggregation Control Protocol (LACP), to negotiate their status. If either of the switches is 'active' (LACP) or 'desirable' (PAgP), then the switch initiates negotiation. If the switch is 'passive' (LACP) or 'auto' (PAgP) then it forms a link aggregation automatically.

LACP

LACP is the Link Aggregation Control Protocol defined by the IEEE 802.3ad standard. It provides a way for both switches to negotiate a port aggregation. With LACP, one or more additional links can operate as standby links that will activate only if an active link goes down.

When connecting two switches with LACP, one of the switches must be in active role to send LACP frames and the other should be set passive.

Compatibility between D-Link Port-Trunking and Cisco Port-Channel

The following table summarizes the options that can be combined to create a trunk on both D-Link and Cisco switches.

Cisco \ D-Link	D-Link		
	Mode On	Mode Passive	Mode Active

Static	✓		
LACP-Passive			✓
LACP- Active		✓	



Note: All ports in a trunk group must be configured at the same speed and VLAN.

Topology




Figure-2 Link Aggregation and VLAN Configuration

Configuration

Static Trunk Configuration on a Cisco Switch

	Command Example	Purpose
Step 1	<pre>Catalyst# config terminal Catalyst(config)# interface range gigabitEthernet 1/0/19-22 Catalyst(config-if)# channel-group 1 mode on</pre>	To create a channel group 1 with static mode.

Static Trunk Configuration on a D-Link Switch

	Command Example	Purpose
--	-----------------	---------

Step 1

```
switch# create link_aggregation group_id 1 type static
switch# config link_aggregation group_id 1 ports 19-22 state
enable
```

To create a trunk group 1 with static mode.

Troubleshooting Examples

Verifying the Static Channel Status on a Cisco Switch

The following example shows you how to correctly set the port mode and verify the channel group ports.

Command Example

```
Catalyst# show etherchannel 1 summary
```

```
Flags:  D - down          P - bundled in port-channel
        I - stand-alone  s - suspended
        H - Hot-standby (LACP only)
        R - Layer3       S - Layer2
        U - in use       f - failed to allocate aggregator

        M - not in use, minimum links not met
        u - unsuitable for bundling
        w - waiting to be aggregated
        d - default port
```

```
Number of channel-groups in use: 1
Number of aggregators:           1
```

Group	Port-channel	Protocol	Ports
1	Po1(SU)	-	Gi1/0/19(P) Gi1/0/20(P) Gi1/0/21(P) Gi1/0/22(P)

```
Catalyst#show etherchannel 1 detail
```

```
Group state = L2
Ports: 4    Maxports = 8
Port-channels: 1 Max Port-channels = 1
Protocol:    -
Minimum Links: 0
```

```
Ports in the group:
```

```
Port: Gi1/0/19
```

```
Port state      = Up Mstr In-Bndl
Channel group   = 1          Mode = On          Gcchange = -
Port-channel    = Po1        GC    = -          Pseudo port-channel = Po1
Port index      = 0          Load = 0x00        Protocol = -
```

```
Age of the port in the current state: 0d:00h:04m:13s
```

Port: Gi1/0/20

```

Port state      = Up Mstr In-Bndl
Channel group   = 1           Mode = On           Gcchange = -
Port-channel    = Po1         GC   = -           Pseudo port-channel = Po1
Port index      = 0           Load = 0x00        Protocol = -

```

Age of the port in the current state: 0d:00h:04m:12s

Port: Gi1/0/21

```

Port state      = Up Mstr In-Bndl
Channel group   = 1           Mode = On           Gcchange = -
Port-channel    = Po1         GC   = -           Pseudo port-channel = Po1
Port index      = 0           Load = 0x00        Protocol = -

```

Age of the port in the current state: 0d:00h:04m:14s

Port: Gi1/0/22

```

Port state      = Up Mstr In-Bndl
Channel group   = 1           Mode = On           Gcchange = -
Port-channel    = Po1         GC   = -           Pseudo port-channel = Po1
Port index      = 0           Load = 0x00        Protocol = -

```

Age of the port in the current state: 0d:00h:04m:13s

Port-channels in the group:

Port-channel: Po1

```

Age of the Port-channel = 0d:00h:04m:17s
Logical slot/port      = 10/1           Number of ports = 4
GC                     = 0x00000000    HotStandBy port = null
Port state              = Port-channel Ag-Inuse
Protocol                = -
Port security           = Disabled

```

Ports in the Port-channel:

Index	Load	Port	EC state	No of bits
0	00	Gi1/0/19	On	0

```

0      00      Gi1/0/20 On      0
0      00      Gi1/0/21 On      0
0      00      Gi1/0/22 On      0

```

```
Time since last port bundled:    0d:00h:04m:14s    Gi1/0/22
```

Verifying the Static Trunk Status on a D-Link Switch

The following example shows you how to correctly set the port mode and verify the channel group ports.

Command Example

```

switch# show link_aggregation
Command: show link_aggregation

Link Aggregation Algorithm = IP-Source
Group ID      : 1
Type          : TRUNK
Master Port   : 19
Member Port   : 19-22
Active Port   : 19-22
Status        : Enabled
Flooding Port : 19

```

LACP Configuration on a Cisco Switch

The following example shows you how to create a channel group, when a switch plays an active role in a LACP trunk.

	Command Example	Purpose
Step 1	<pre> Catalyst# config terminal Catalyst(config)# interface range gigabitEthernet 1/0/19-22 Catalyst(config-if)# channel-group 1 mode active </pre>	To create a channel group 1 with LACP-active mode.

The following example shows you how to create a channel group, when a switch plays a passive role in a LACP trunk.

	Command Example	Purpose
Step 1	<pre>Catalyst# config terminal Catalyst(config)# interface range gigabitEthernet 1/0/19-22 Catalyst(config-if)# channel-group 1 mode passive</pre>	To create a channel group 1 with LACP-passive mode.

LACP Configuration on a D-Link Switch

The following example shows you how to create a trunk group, when a switch plays an active role in a LACP trunk.

	Command Example	Purpose
Step 1	<pre>switch# create link_aggregation group_id 1 type lacp switch# config link_aggregation group_id 1 master_port 19 ports 19-22 state enable switch# config lacp_port 19-22 mode active</pre>	To create a trunk group 1 with LACP-active mode.

The following example shows you how to create a trunk group, when a switch plays a passive role in a LACP trunk.

	Command Example	Purpose
Step 1	<pre>switch# create link_aggregation group_id 1 type lacp switch# config link_aggregation group_id 1 master_port 19 ports 19-22 state enable switch# config lacp_port 19-22 mode passive</pre>	To create a trunk group 1 with LACP-passive mode.



Note: By default, the LACP port mode is set passive in D-Link switches.

Verifying the LACP Configuration on a Cisco Switch

The following example shows you how to correctly set the port mode and verify the channel group ports.

Command Example

```
Catalyst# show interfaces etherchannel
```

```
----
```

```
GigabitEthernet1/0/19:
```

```
Port state      = Up Sngl-port-Bndl Mstr Not-in-Bndl
```

```
Channel group   = 1          Mode = Active          Gcchange = -
```

```
Port-channel    = null      GC    = -              Pseudo port-channel = Po1
```

```
Port index      = 0          Load = 0x00          Protocol = LACP
```

Flags: S - Device is sending Slow LACPDUs F - Device is sending fast LACPDUs.
 A - Device is in active mode. P - Device is in passive mode.

Local information:

Port	Flags	State	LACP port Priority	Admin Key	Oper Key	Port Number	Port State
Gi1/0/19	SA	indep	32768	0x1	0x1	0x13	0x7D

Age of the port in the current state: 0d:00h:00m:51s

GigabitEthernet1/0/20:

Port state = Up Sngl-port-Bndl Mstr Not-in-Bndl

Channel group = 1 Mode = **Active** Gcchange = -

Port-channel = null GC = - Pseudo port-channel = Po1

Port index = 0 Load = 0x00 Protocol = LACP

Flags: S - Device is sending Slow LACPDUs F - Device is sending fast LACPDUs.
 A - Device is in active mode. P - Device is in passive mode.

Local information:

Port	Flags	State	LACP port Priority	Admin Key	Oper Key	Port Number	Port State
Gi1/0/20	SA	indep	32768	0x1	0x1	0x14	0x7D

Age of the port in the current state: 0d:00h:00m:51s

GigabitEthernet1/0/21:

Port state = Up Sngl-port-Bndl Mstr Not-in-Bndl

Channel group = 1 Mode = **Active** Gcchange = -

Port-channel = null GC = - Pseudo port-channel = Po1

Port index = 0 Load = 0x00 Protocol = LACP

Flags: S - Device is sending Slow LACPDUs F - Device is sending fast LACPDUs.
 A - Device is in active mode. P - Device is in passive mode.

Local information:

Port	Flags	State	LACP port Priority	Admin Key	Oper Key	Port Number	Port State
Gi1/0/21	SA	indep	32768	0x1	0x1	0x15	0x7D

Age of the port in the current state: 0d:00h:00m:55s

GigabitEthernet1/0/22:

Port state = Up Sngl-port-Bndl Mstr Not-in-Bndl

Channel group = 1 Mode = **Active** Gcchange = -

Port-channel = null GC = - Pseudo port-channel = Po1

```

Port index      = 0          Load = 0x00          Protocol =   LACP

Flags:  S - Device is sending Slow LACPDUs    F - Device is sending fast LACPDUs.
       A - Device is in active mode.          P - Device is in passive mode.

Local information:

Port      Flags   State      LACP port   Admin   Oper   Port   Port
Gi1/0/22  SA      indep     32768       0x1     0x1    0x16   0x7D

Age of the port in the current state: 0d:00h:00m:55s

----
Port-channel1:Port-channel1   (Primary aggregator)

Age of the Port-channel   = 0d:01h:42m:42s
Logical slot/port        = 10/1          Number of ports = 0
HotStandBy port = null
Port state               = Port-channel Ag-Not-Inuse
Protocol                 =   LACP
Port security            = Disabled

Time since last port bundled:    0d:01h:42m:38s    Gi1/0/22
Time since last port Un-bundled: 0d:00h:01m:19s    Gi1/0/22

```

Verifying the LACP Configuration on a D-Link Switch

The following example shows you how to correctly set the ports of a trunk group.

Command Example

```

switch# show link_aggregation
Command: show link_aggregation

Link Aggregation Algorithm = IP-Source
Group ID      : 1
Type         : LACP
Master Port   : 19
Member Port   : 19-22
Active Port   : 19-22
Status        : Enabled
Flooding Port : 21

Total Entries : 1

```

The following example shows you how to correctly set the port mode.

Command Example

```
switch# show lacp
```

```
Command: show lacp_port
```

Port	Activity
-----	-----
1	Passive
2	Passive
3	Passive
:	
19	Passive
20	Passive
21	Passive
22	Passive

Spanning Tree Configuration

Terminology

Cisco	D-Link	Description
Port Fast	Edge Port	Bypassing the listening and learning stages, this port changes its state from blocking to forwarding directly to speed up Spanning tree protocol (STP) convergence.



Note: Since STP/Rapid STP (RSTP) function can only run in a single VLAN, all connections on Per-VLAN Spanning Tree (PVST) should be located in the same VLAN.

Topology




Figure-3 Spanning Tree Configuration

Configuration

Rapid-PVST Configuration on a Cisco Switch

	Command Example	Purpose
Step 1	Catalyst# config terminal Catalyst(config)# spanning-tree mode rapid-pvst	To enable STP and choose rapid-PVST mode.
Step 2	Catalyst(config)# spanning-tree vlan 1 priority 4096	To change priority to 4096.

RSTP Configuration on a D-Link Switch

	Command Example	Purpose
Step 1	switch:admin# enable stp switch:admin# config stp version rstp	To enable and then choose RSTP.
Step 2	switch:admin# config stp ports 1-22 edge true switch:admin# config stp ports 23-24 p2p true	Assume ports 1-22 are connected to PCs or an end terminal device. These ports should be set as edge ports. The ports 23-24 which are connected to the switch should be set as P2P ports.

Troubleshooting Examples

Verifying RSTP Mode and Ports Status on a Cisco Switch

The following example shows you how to verify the STP protocol version, STP priority and port.

Command Example

```
Catalyst# show span vlan 1
```

```
VLAN0001
```

```
Spanning tree enabled protocol rstp
```

```
Root ID      Priority    4097
```

```
Address      0021.56b0.5c00
```

```
This bridge is the root
```

```
Hello Time   2 sec  Max Age 20 sec  Forward Delay 15 sec
```

```
Bridge ID    Priority    4097 (priority 4096 sys-id-ext 1)
```

```
Address      0021.56b0.5c00
```

```
Hello Time   2 sec  Max Age 20 sec  Forward Delay 15 sec
```

```
Aging Time 300
```

```
Interface      Role Sts Cost      Prio.Nbr Type
```

```
-----
```

```
Gi1/0/23       Desg FWD 4        128.23  P2p
```

```
Gi1/0/24       Desg FWD 4        128.24  P2p
```

The following example shows you how to check STP detail information.

Command Example

```
Catalyst# show spanning-tree detail
```

```

VLAN0001 is executing the rstp compatible Spanning Tree protocol
Bridge Identifier has priority 4096, sysid 1, address 0021.56b0.5c00
Configured hello time 2, max age 20, forward delay 15, transmit hold-count 6
We are the root of the spanning tree
Topology change flag not set, detected flag not set
Number of topology changes 4 last change occurred 00:25:48 ago
    from GigabitEthernet1/0/23
Times:  hold 1, topology change 35, notification 2
        hello 2, max age 20, forward delay 15
Timers: hello 0, topology change 0, notification 0, aging 300

```

```

Port 23 (GigabitEthernet1/0/23) of VLAN0001 is designated forwarding
Port path cost 4, Port priority 128, Port Identifier 128.23.
Designated root has priority 4097, address 0021.56b0.5c00
Designated bridge has priority 4097, address 0021.56b0.5c00
Designated port id is 128.23, designated path cost 0
Timers: message age 0, forward delay 0, hold 0
Number of transitions to forwarding state: 2
Link type is point-to-point by default
BPDU: sent 839, received 22

```

```

Port 24 (GigabitEthernet1/0/24) of VLAN0001 is designated forwarding
Port path cost 4, Port priority 128, Port Identifier 128.24.
Designated root has priority 4097, address 0021.56b0.5c00
Designated bridge has priority 4097, address 0021.56b0.5c00
Designated port id is 128.24, designated path cost 0
Timers: message age 0, forward delay 0, hold 0
Number of transitions to forwarding state: 1
Link type is point-to-point by default
BPDU: sent 779, received 65

```

Verifying the RSTP Mode and Ports Status on a D-Link Switch

The following example shows you how to verify if the spanning mode is RSTP and STP is enabled.

Command Example

```
switch:admin# show stp
```

```
Command: show stp
```

STP Bridge Global Settings

```
-----
```

```
STP Status           : Enabled
STP Version          : RSTP
Max Age              : 20
Hello Time           : 2
Forward Delay        : 15
Max Hops             : 2
TX Hold Count        : 6
Forwarding BPDU      : Disabled
Loopback Detection   : Enabled
LBD Recover Time     : 60
NNI BPDU Address     : dot1ad
```

The following example shows you how to verify the Root Bridge.

Command Example

```
switch:admin# show stp instance 0
```

```
Command: show stp instance 0
```

STP Instance Settings

```
-----
```

```
Instance Type        : CIST
Instance Status      : Enabled
Instance Priority     : 32768(Bridge Priority : 32768, SYS ID Ext : 0 )
```

STP Instance Operational Status

```
-----
```

```
Designated Root Bridge : 4097 /00-21-56-B0-5C-00
External Root Cost      : 20000
Regional Root Bridge  : 32768/00-19-5B-12-43-00
Internal Root Cost      : 0
Designated Bridge       : 4097 /00-21-56-B0-5C-00
Root Port               : 23
Max Age                 : 20
Forward Delay           : 15
Last Topology Change    : 978
Topology Changes Count  : 5
```

The following example shows you how to verify the role of the interface.

Command Example

```
switch:admin# show stp ports 23
```

```
Command: show stp ports 23
```

MSTP Port Information

```
-----
```

```
Port Index      : 23      , Hello Time: 2 /2 , Port STP : Enabled , LBD : No
```

```
External PathCost : Auto/20000 , Edge Port : False/No , P2P : True /Yes
```

```
Port RestrictedRole : False, Port RestrictedTCN : False
```

```
Port Forward BPDU : Disabled
```

MSTI	Designated Bridge	Internal PathCost	Prio	Status	Role
------	-------------------	-------------------	------	--------	------

```
-----
```

0	1001/002156B05C00	20000	128	Forwarding	Root
---	-------------------	-------	-----	------------	------

Multiple Spanning Tree Configuration

Terminology

None

Compatibility between MSTP and PVST

The following table summarizes the compatibility of PVST and MSTP functions.

Cisco D-Link	PVST	PVST+	Rapid PVST+
MSTP	No	Yes (See note)	Yes (reverts to PVST+)



Note: In a MSTP and PVST+ network, the Common Spanning-Tree (CST) root must be inside the MST backbone, and a PVST+ switch cannot connect to multiple MST regions.

Topology




Figure-4 Multiple Spanning Tree Configuration

Configuration

Multiple Spanning Configuration on a Cisco Switch

	Command Example	Purpose
Step 1	Catalyst# config terminal Catalyst(config)# vlan 10,20,30	To create VLAN interface for ports 10 and 20.
Step 2	Catalyst(config)# interface range gigabitEthernet 1/0/1-8 Catalyst(config-if-range)# switchport access vlan 10 Catalyst(config-if-range)# interface range gigabitEthernet 1/0/9-16 Catalyst(config-if-range)# switchport access vlan 20	To assign interfaces for 0/1/0-8 to VLAN 10 and 0/1/9-16 to VLAN 20.
Step 3	Catalyst(config)# interface range gigabitEthernet 1/0/23-24 Catalyst(config-if-range)# switchport mode trunk Catalyst(config-if-range)# switchport trunk allowed vlan 1,10,20 Catalyst(config-if-range)# switchport trunk encapsulation dot1q	To set interfaces for 0/1/23-24 as the trunk interfaces.
Step 4	Catalyst(config)# interface vlan 10 Catalyst(config-if)# ip address 192.168.10.1 255.255.255.0 Catalyst(config)# interface vlan 20 Catalyst(config-if)# ip address 192.168.20.1 255.255.255.0	To create two IP interfaces on VLAN 10 and 20.
Step 5	Catalyst(config)# spanning-tree mode mst Catalyst(config)# spanning-tree mst configuration Catalyst(config-mst)# name test Catalyst(config-mst)# revision 1 Catalyst(config-mst)# instance 1 vlan 10 Catalyst(config-mst)# instance 2 vlan 20	To set up Multiple Spanning Tree name/revision/instance and VLAN mapping as the same value on all switches.
Step 6	Catalyst(config)# spanning-tree mst 1 priority 4096 Catalyst(config)# spanning-tree mst 2 priority 4096 Catalyst(config)# spanning-tree mst 3 priority 4096	To set Cisco switch as the root switch.

Multiple Spanning Configuration on a D-Link Switch

	Command Example	Purpose
Step 1	switch:admin# create vlan 10 tag 10 switch:admin# create vlan 20 tag 20 switch:admin# config vlan default delete 1-16	To create VLAN interfaces for ports 10, 20 and port

	switch:admin# config vlan 10 add untagged 1-8 switch:admin# config vlan 10 add tagged 23-24 switch:admin# config vlan 20 add untagged 9-16 switch:admin# config vlan 20 add tagged 23-24	assignment.
Step 2	switch:admin# create ipif 10 192.168.10.2/24 10 switch:admin# create ipif 20 192.168.20.2/24 20	To create two IP interfaces on VLAN 10 and 20.
Step 3	switch:admin# config stp mst_config_id name test switch:admin# config stp mst_config_id revision_level 1 switch:admin# config stp version mstp switch:admin# create stp instance_id 1 switch:admin# create stp instance_id 2 switch:admin# config stp instance_id 1 add_vlan 10 switch:admin# config stp instance_id 2 add_vlan 20 switch:admin# enable stp	To set up Multiple Spanning Tree name/revision/instance and VLAN mapping as the same value on all switches.

Troubleshooting Examples

Verifying MSTP Mode and Ports Status on a Cisco Switch

The following example shows you how to verify an MSTP instance and VLAN mapping information.

Command Example

```
Catalyst(config-mst)# show pending
Pending MST configuration
Name      [test]
Revision  1      Instances configured 3
```

```
Instance  Vlans mapped
-----
```

```
0          1-9,11-19,21-4094
```

```
1          10
```

```
2          20
-----
```

```
Catalyst# show spanning-tree mst configuration
```

```
Name      [test]
Revision  1      Instances configured 3
```

```
Instance  Vlans mapped
-----
```

```
0          1-9,11-19,21-4094
```

```
1          10
```

```
2          20
-----
```

The following example shows you how to check STP information.

Command Example

Catalyst# **show spanning-tree detail**

```
VLAN0001 is executing the rstp compatible Spanning Tree protocol
Bridge Identifier has priority 4096, sysid 1, address 0021.56b0.5c00
Configured hello time 2, max age 20, forward delay 15, transmit hold-count 6
We are the root of the spanning tree
Topology change flag not set, detected flag not set
Number of topology changes 4 last change occurred 00:25:48 ago
    from GigabitEthernet1/0/23
Times: hold 1, topology change 35, notification 2
    hello 2, max age 20, forward delay 15
Timers: hello 0, topology change 0, notification 0, aging 300

Port 23 (GigabitEthernet1/0/23) of VLAN0001 is designated forwarding
Port path cost 4, Port priority 128, Port Identifier 128.23.
Designated root has priority 4097, address 0021.56b0.5c00
Designated bridge has priority 4097, address 0021.56b0.5c00
Designated port id is 128.23, designated path cost 0
Timers: message age 0, forward delay 0, hold 0
Number of transitions to forwarding state: 2
Link type is point-to-point by default
BPDU: sent 839, received 22

Port 24 (GigabitEthernet1/0/24) of VLAN0001 is designated forwarding
Port path cost 4, Port priority 128, Port Identifier 128.24.
Designated root has priority 4097, address 0021.56b0.5c00
Designated bridge has priority 4097, address 0021.56b0.5c00
Designated port id is 128.24, designated path cost 0
Timers: message age 0, forward delay 0, hold 0
Number of transitions to forwarding state: 1
Link type is point-to-point by default
BPDU: sent 779, received 65
```

The following example shows you how to check the STP status.

Command Example

Catalyst# **show spanning-tree**

MST0

Spanning tree enabled protocol mstp

Root ID Priority 4096
 Address 0021.56b0.5c00
 This bridge is the root
 Hello Time 2 sec Max Age 20 sec Forward Delay 15 sec

Bridge ID Priority 4096 (priority 4096 sys-id-ext 0)
 Address 0021.56b0.5c00
 Hello Time 2 sec Max Age 20 sec Forward Delay 15 sec

Interface	Role	Sts	Cost	Prio.Nbr	Type
Gi1/0/1	Desg	FWD	200000	128.1	P2p Edge
Gi1/0/9	Desg	FWD	200000	128.9	P2p Edge
Gi1/0/23	Desg	FWD	20000	128.23	P2p
Gi1/0/24	Desg	FWD	20000	128.24	P2p

MST1

Spanning tree enabled protocol mstp

Root ID Priority 4097
 Address 0021.56b0.5c00
 This bridge is the root
 Hello Time 2 sec Max Age 20 sec Forward Delay 15 sec

Bridge ID Priority 4097 (priority 4096 sys-id-ext 1)
 Address 0021.56b0.5c00
 Hello Time 2 sec Max Age 20 sec Forward Delay 15 sec

Interface	Role	Sts	Cost	Prio.Nbr	Type
Gi1/0/1	Desg	FWD	200000	128.1	P2p Edge
Gi1/0/23	Desg	FWD	20000	128.23	P2p
Gi1/0/24	Desg	FWD	20000	128.24	P2p

MST2

Spanning tree enabled protocol mstp

Root ID Priority 4098
 Address 0021.56b0.5c00
 This bridge is the root
 Hello Time 2 sec Max Age 20 sec Forward Delay 15 sec

Bridge ID Priority 4098 (priority 4096 sys-id-ext 2)
 Address 0021.56b0.5c00

Hello Time 2 sec Max Age 20 sec Forward Delay 15 sec

Interface	Role	Sts	Cost	Prio.Nbr	Type
-----	-----	-----	-----	-----	-----
Gi1/0/9	Desg	FWD	200000	128.9	P2p Edge
Gi1/0/23	Desg	FWD	20000	128.23	P2p
Gi1/0/24	Desg	FWD	20000	128.24	P2p

The following example shows you how to check the MST protocol information.

Command Example

Catalyst# **show spanning-tree mst**

```
##### MST0      vlans mapped: 1-9,11-19,21-4094
Bridge          address 0021.56b0.5c00 priority      4096 (4096 sysid 0)
Root            this switch for the CIST
Operational     hello time 2 , forward delay 15, max age 20, txholdcount 6
Configured      hello time 2 , forward delay 15, max age 20, max hops 20
```

Interface	Role	Sts	Cost	Prio.Nbr	Type
-----	-----	-----	-----	-----	-----
Gi1/0/1	Desg	FWD	200000	128.1	P2p Edge
Gi1/0/9	Desg	FWD	200000	128.9	P2p Edge
Gi1/0/23	Desg	FWD	20000	128.23	P2p
Gi1/0/24	Desg	FWD	20000	128.24	P2p

```
##### MST1      vlans mapped: 10
Bridge          address 0021.56b0.5c00 priority      4097 (4096 sysid 1)
Root            this switch for MST1
```

Interface	Role	Sts	Cost	Prio.Nbr	Type
-----	-----	-----	-----	-----	-----
Gi1/0/1	Desg	FWD	200000	128.1	P2p Edge
Gi1/0/23	Desg	FWD	20000	128.23	P2p
Gi1/0/24	Desg	FWD	20000	128.24	P2p

```
##### MST2      vlans mapped: 20
Bridge          address 0021.56b0.5c00 priority      4098 (4096 sysid 2)
Root            this switch for MST2
```

Interface	Role	Sts	Cost	Prio.Nbr	Type
-----	-----	-----	-----	-----	-----
Gi1/0/9	Desg	FWD	200000	128.9	P2p Edge
Gi1/0/23	Desg	FWD	20000	128.23	P2p
Gi1/0/24	Desg	FWD	20000	128.24	P2p

Verifying the RSTP Mode and Ports Status on a D-Link Switch

The following example shows you how to verify if the spanning mode is MSTP and STP is enabled.

Command Example

```
switch:admin# show stp
```

```
Command: show stp
```

STP Bridge Global Settings

```
-----
```

```
STP Status           : Enabled
```

```
STP Version          : MSTP
```

```
Max Age              : 20
```

```
Forward Delay        : 15
```

```
Max Hops             : 20
```

```
TX Hold Count        : 6
```

```
Forwarding BPDU      : Disabled
```

```
Loopback Detection   : Enabled
```

```
LBD Recover Time    : 60
```

```
NNI BPDU Address    : dot1ad
```

The following example shows you how to check the spanning instance information.

Command Example

```
switch:admin# show stp instance 0
```

```
Command: show stp instance 0
```

STP Instance Settings

```
-----
```

```
Instance Type        : CIST
```

```
Instance Status      : Enabled
```

```
Instance Priority     : 32768(Bridge Priority : 32768, SYS ID Ext : 0 )
```

STP Instance Operational Status

```
-----
```

```
Designated Root Bridge : 32768/00-19-5B-12-43-00
```

```
External Root Cost      : 0
```

```
Regional Root Bridge    : 32768/00-19-5B-12-43-00
```

```
Internal Root Cost      : 0
```

```
Designated Bridge       : 32768/00-19-5B-12-43-00
```

```
Root Port               : None
```

```
Max Age                 : 20
```

```
Forward Delay           : 15
```

```
Last Topology Change    : 74717
```

```
Topology Changes Count  : 22
```

The following example shows you how to check the STP instance and VLAN mapping.

Command Example

```
switch:admin# show stp mst_config_id
```

```
Command: show stp mst_config_id
```

```
Current MST Configuration Identification
```

```
-----
```

```
Configuration Name : test
```

```
Revision Level :1
```

```
MSTI ID      Vid list
```

```
-----
```

```
  CIST      1-9,11-19,21-4094
```

```
    1        10
```

```
    2        20
```

Open Shortest Path Fast (OSPF) Configuration

Terminology

None

Topology – Single OSPF Area




Figure-5 Single OSPF Area Configuration

Configuration

OSPF Configuration on a Cisco Switch - 1

	Command Example	Purpose
Step 1	<pre> Catalyst# config terminal Catalyst(config)# interface gigabitEthernet 1/0/23 Catalyst(config-if)# no switchport Catalyst(config-if)# ip address 192.168.20.2 255.255.255.0 Catalyst(config-if)# no shut Catalyst(config-if)# exit Catalyst(config)# interface gigabitEthernet 1/0/22 Catalyst(config-if)# no switchport Catalyst(config-if)# ip address 192.168.30.1 255.255.255.0 Catalyst(config-if)# no shutdown Catalyst(config-if)# exit </pre>	To create two IP interfaces - (192.168.20.0/192.168.30.0)
Step 2	<pre> Catalyst(config)# ip routing Catalyst(config)# router ospf 100 </pre>	To enable OSPF on specific interfaces and

```
Catalyst(config-router)# router-id 192.168.20.1
Catalyst(config-router)# network 192.168.20.0 0.0.0.255
area 0
Catalyst(config-router)# network 192.168.30.0 0.0.0.255
area 0
```

set up router ID.

OSPF Configuration on a Cisco Switch - 2

	Command Example	Purpose
Step 1	<pre>Catalyst# config terminal Catalyst(config)# interface gigabitEthernet 1/0/23 Catalyst(config-if)# no switchport Catalyst(config-if)# ip address 192.168.40.2 255.255.255.0 Catalyst(config-if)# no shut Catalyst(config-if)# exit Catalyst(config)# interface gigabitEthernet 1/0/22 Catalyst(config-if)# no switchport Catalyst(config-if)# ip address 192.168.30.1 255.255.255.0 Catalyst(config-if)# no shutdown Catalyst(config-if)# exit</pre>	To create two IP interfaces (192.168.30.0 / 192.168.40.0).
Step 2	<pre>Catalyst(config)# ip routing Catalyst(config)# router ospf 100 Catalyst(config-router)# router-id 192.168.30.1 Catalyst(config-router)# network 192.168.30.0 0.0.0.255 area 0 Catalyst(config-router)# network 192.168.40.0 0.0.0.255 area 0</pre>	To enable OSPF on specific interfaces and set up router ID.

OSPF Configuration on a D-Link Switch - 1

	Command Example	Purpose
Step 1	<pre>switch:admin# create vlan 10 tag 10 switch:admin# create vlan 20 tag 20 switch:admin# config vlan default delete 1-16 switch:admin# config vlan 10 add untagged 1-8 switch:admin# config vlan 20 add untagged 9-16,23</pre>	To create VLAN interfaces for ports 10 and 20 and assign relative ports to each VLAN.
Step 2	<pre>switch:admin# create ipif 10 192.168.10.1/24 10 switch:admin# create ipif 20 192.168.20.1/24 20</pre>	To create two IP interfaces on VLAN 10 and 20.
Step 3	<pre>config ospf router_id 192.168.10.1 switch:admin# config ospf ipif 10 area 0.0.0.0 state enable switch:admin# config ospf ipif 20 area 0.0.0.0 state enable switch:admin# enable ospf</pre>	To enable OSPF on specific interfaces and set up router ID.

OSPF Configuration on a D-Link Switch - 2

	Command Example	Purpose
Step 1	<pre>switch:admin# create vlan 40 tag 40 switch:admin# create vlan 50 tag 50 switch:admin# config vlan default delete 1-16 switch:admin# config vlan 40 add untagged 1-8,24 switch:admin# config vlan 50 add untagged 9-16</pre>	To create VLAN interfaces for ports 40 and 50 and assign relative ports to each VLAN.
Step 2	<pre>switch:admin# create ipif 40 192.168.10.1/24 40 switch:admin# create ipif 50 192.168.20.1/24 50</pre>	To create two IP interfaces on VLAN 40 and 50.
Step 3	<pre>config ospf router_id 192.168.40.1 switch:admin# config ospf ipif 40 area 0.0.0.0 state enable switch:admin# config ospf ipif 50 area 0.0.0.0 state enable switch:admin# enable ospf</pre>	To enable OSPF on specific interfaces and set up router ID.

Troubleshooting Examples

Verifying OSPF Information on a Cisco Switch

The following example shows you how to check OSPF information.

Command Example

```
Catalyst# show ip ospf
Routing Process "ospf 100" with ID 192.168.20.1
Start time: 00:01:21.528, Time elapsed: 00:00:52.454
Supports only single TOS(TOS0) routes
Supports opaque LSA
Supports Link-local Signaling (LLS)
Supports area transit capability
Router is not originating router-LSAs with maximum metric
Initial SPF schedule delay 5000 msecs
Minimum hold time between two consecutive SPFs 10000 msecs
Maximum wait time between two consecutive SPFs 10000 msecs
Incremental-SPF disabled
Minimum LSA interval
*Mar  1 00:02:12.623: %OSPF-5-ADJCHG: Process 100, Nbr 192.168.30.1 on
GigabitEthernet1/0/22 from LOADING to FULL, Loading Done5 secs
Minimum LSA arrival 1000 msecs
LSA group pacing timer 240 secs
Interface flood pacing timer 33 msecs
Retransmission pacing timer 66 msecs
Number of external LSA 0. Checksum Sum 0x000000
Number of opaque AS LSA 0. Checksum Sum 0x000000
Number of DCbitless external and opaque AS LSA 0
Number of DoNotAge external and opaque AS LSA 0
Number of areas in this router is 1. 1 normal 0 stub 0 nssa
Number of areas transit capable is 0
External flood list length 0
IETF NSF helper support enabled
Cisco NSF helper support enabled
Reference bandwidth unit is 100 mbps
  Area BACKBONE(0)
    Number of interfaces in this area is 2
    Area has no authentication
    SPF algorithm last executed 00:00:37.984 ago
    SPF algorithm executed 2 times
    Area ranges are
    Number of LSA 8. Checksum Sum 0x043353
    Number of opaque link LSA 0. Checksum Sum 0x000000
    Number of DCbitless LSA 4
    Number of indication LSA 0
    Number of DoNotAge LSA 0
```

Flood list length 0

The following example shows you how to verify if the OSPF neighbors are established.

Command Example

```
Catalyst# show ip ospf neighbor
```

Neighbor ID	Pri	State	Dead Time	Address	Interface
192.168.30.1	1	FULL/DR	00:00:38	192.168.30.2	GigabitEthernet1/0/22
192.168.10.1	1	FULL/DR	00:00:36	192.168.20.1	GigabitEthernet1/0/23

The following example shows you how to verify if the route entries are learnt by the switches.

Command Example

```
Catalyst# show ip route
```

Codes: C - connected, S - static, R - RIP, M - mobile, B - BGP
 D - EIGRP, EX - EIGRP external, O - OSPF, IA - OSPF inter area
 N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2
 E1 - OSPF external type 1, E2 - OSPF external type 2
 i - IS-IS, su - IS-IS summary, L1 - IS-IS level-1, L2 - IS-IS level-2
 ia - IS-IS inter area, * - candidate default, U - per-user static route
 o - ODR, P - periodic downloaded static route

Gateway of last resort is not set

```
C    192.168.30.0/24 is directly connected, GigabitEthernet1/0/22
O    192.168.10.0/24 [110/2] via 192.168.20.1, 00:02:07, GigabitEthernet1/0/23
O    192.168.40.0/24 [110/2] via 192.168.30.2, 00:02:07, GigabitEthernet1/0/22
C    192.168.20.0/24 is directly connected, GigabitEthernet1/0/23
O    192.168.50.0/24 [110/3] via 192.168.30.2, 00:02:07, GigabitEthernet1/0/22
```

The following example shows you how to check the OSPF interface status.

Command Example

```
Catalyst# show ip ospf interface
```

```
GigabitEthernet1/0/22 is up, line protocol is up (connected)
```

```
Internet Address 192.168.30.1/24, Area 0
```

```
Process ID 100, Router ID 192.168.20.1, Network Type BROADCAST, Cost: 1
```

```
Transmit Delay is 1 sec, State BDR, Priority 1
```

```
Designated Router (ID) 192.168.30.1, Interface address 192.168.30.2
```

```
Backup Designated router (ID) 192.168.20.1, Interface address 192.168.30.1
```

```
Timer intervals configured, Hello 10, Dead 40, Wait 40, Retransmit 5
```

```
oob-resync timeout 40
```

```
Hello due in 00:00:01
```

```

Supports Link-local Signaling (LLS)
Cisco NSF helper support enabled
IETF NSF helper support enabled
Index 2/2, flood queue length 0
Next 0x0(0)/0x0(0)
Last flood scan length is 1, maximum is 1
Last flood scan time is 0 msec, maximum is 0 msec
Neighbor Count is 1, Adjacent neighbor count is 1
  Adjacent with neighbor 192.168.30.1 (Designated Router)
Suppress hello for 0 neighbor(s)
GigabitEthernet1/0/23 is up, line protocol is up (connected)
Internet Address 192.168.20.2/24, Area 0
Process ID 100, Router ID 192.168.20.1, Network Type BROADCAST, Cost: 1
Transmit Delay is 1 sec, State BDR, Priority 1
Designated Router (ID) 192.168.10.1, Interface address 192.168.20.1
Backup Designated router (ID) 192.168.20.1, Interface address 192.168.20.2
Timer intervals configured, Hello 10, Dead 40, Wait 40, Retransmit 5
  oob-resync timeout 40
  Hello due in 00:00:07
Supports Link-local Signaling (LLS)
Cisco NSF helper support enabled
IETF NSF helper support enabled
Index 1/1, flood queue length 0
Next 0x0(0)/0x0(0)
Last flood scan length is 1, maximum is 5
Last flood scan time is 0 msec, maximum is 0 msec
Neighbor Count is 1, Adjacent neighbor count is 1
  Adjacent with neighbor 192.168.10.1 (Designated Router)
Suppress hello for 0 neighbor(s)

```

Verifying the OSPF Status on a D-Link Switch

The following example shows you how to verify if the OSPF is enabled on correct interfaces.

Command Example

```

switch:admin# show ospf
Command: show ospf

```

```

OSPF Router ID : 192.168.10.1
State          : Enabled

```

OSPF Interface Settings

Interface	IP Address	Area ID	State	Link Status	Metric
-----	-----	-----	-----	-----	-----
System	10.90.90.90/8	0.0.0.0	Disabled	Link Up	1
10	192.168.10.1/24	0.0.0.0	Enabled	Link Up	1

20 192.168.20.1/24 0.0.0.0 Enabled Link Up 1

Total Entries : 3

OSPF Area Settings

Area ID	Type	Stub	Import Summary	LSA	Stub Default	Cost	Translate
0.0.0.0	Normal	None			None		None

Total Entries : 1

Virtual Interface Configuration

Transit Area ID	Virtual Neighbor	Router Interval	Hello Interval	Dead	Authentication Status	Link
-----	-----	-----	-----	-----	-----	-----

Total Entries : 0

OSPF Area Aggregation Settings

Area ID	Aggregated Network Address	LSDB Type	Advertise
-----	-----	-----	-----

Total Entries : 0

OSPF Host Route Settings

Host Address	Metric	Area ID
-----	-----	-----

Total Entries : 0

The following example shows you how to verify if the OSPF neighbor is established.

Command Example

```
switch:admin# show ospf neighbor
Command: show ospf neighbor
```

IP Address of Neighbor	Router ID of Neighbor	Neighbor Priority	Neighbor State
-----	-----	-----	-----
192.168.20.2	192.168.20.2	1	Full

Total Entries : 1

The following example shows you how to check the OSPF interface information.

Command Example

```
switch:admin# show ospf ipif 10
```

```
Command: show ospf ipif 10
```

```
Interface Name: 10                      IP Address: 192.168.10.1/24 (Link Up)
Network Medium Type: BROADCAST          Metric: 1
Area ID: 0.0.0.0                        Administrative State: Enabled
Priority: 1                              DR State: DR
DR Address: 192.168.10.1                Backup DR Address: None
Hello Interval: 10                      Dead Interval: 40
Transmit Delay: 1                       Retransmit Time: 5
Authentication: None
```

```
Passive Mode: Disabled
```

```
Total Entries : 1
```

The following example shows you how to verify all the route entries that are learnt by the switches.

Command Example

```
switch:admin# show iproute
```

```
Command: show iproute
```

Routing Table

IP Address/Netmask	Gateway	Interface	Cost	Protocol
10.0.0.0/8	0.0.0.0	System	1	Local
192.168.10.0/24	0.0.0.0	10	1	Local
192.168.20.0/24	0.0.0.0	20	1	Local
192.168.30.0/24	192.168.20.2	20	2	OSPF
192.168.40.0/24	192.168.20.2	20	3	OSPF
192.168.50.0/24	192.168.20.2	20	4	OSPF

```
Total Entries : 6
```

```
Total Entries : 1
```

Topology – Single OSPF Area



Figure-6 Multiple OSPF Areas Configuration

Configuration

OSPF Configuration on Cisco Switch – 1

	Command Example	Purpose
Step 1	<pre>Switch#config terminal Switch(config)#interface gigabitEthernet 1/0/23 Switch(config-if)#no switchport Switch(config-if)#ip address 192.168.20.2 255.255.255.0 Switch(config-if)#no shut Switch(config-if)#exit Switch(config)#interface gigabitEthernet 1/0/22 Switch(config-if)#no switchport Switch(config-if)#ip address 192.168.30.1 255.255.255.0 Switch(config-if)#no shutdown Switch(config-if)#exit</pre>	Create two IP interfaces (192.168.20.0 / 192.168.30.0)
Step 2	<pre>Switch(config)#interface loopback 0 Switch(config-if)#ip address 10.0.0.1 255.255.255.255 Switch(config-if)#no shut</pre>	Create a Loopback interface for router ID. Cisco router prefers the address of loopback interface over the

		address of all physical interfaces while choosing router ID.
Step 3	<pre>Switch(config)#ip routing Switch(config)#router ospf 100 Switch(config-router)#network 192.168.20.0 0.0.0.255 area 1 Switch(config-router)#network 192.168.30.0 0.0.0.255 area 0</pre>	Enable OSPF on specific interfaces.

OSPF Configuration on Cisco Switch – 2

	Command Example	Purpose
Step 1	<pre>Switch#config terminal Switch(config)#interface gigabitEthernet 1/0/23 Switch(config-if)#no switchport Switch(config-if)#ip address 192.168.40.2 255.255.255.0 Switch(config-if)#no shut Switch(config-if)#exit Switch(config)#interface gigabitEthernet 1/0/22 Switch(config-if)#no switchport Switch(config-if)#ip address 192.168.30.1 255.255.255.0 Switch(config-if)#no shutdown Switch(config-if)#exit</pre>	Create two IP interfaces (192.168.30.0 / 192.168.40.0)
Step 2	<pre>Switch(config)#interface loopback 0 Switch(config-if)#ip address 10.0.0.2 255.255.255.255 Switch(config-if)#no shut</pre>	Create a Loopback interface for router ID. Cisco router prefers the address of loopback interface over the address of all physical interfaces while choosing router ID.
Step 3	<pre>Switch(config)#ip routing Switch(config)#router ospf 100 Switch(config-router)#router-id 192.168.30.1 Switch(config-router)#network 192.168.30.0 0.0.0.255 area 0 Switch(config-router)#network 192.168.40.0 0.0.0.255 area 2</pre>	Enable OSPF on specific interfaces and set up router ID

OSPF Configuration on D-Link Switch – 1

	Command Example	Purpose
--	-----------------	---------

Step 1	<pre>DGS-3627:admin#create vlan 10 tag 10 DGS-3627:admin#create vlan 20 tag 20 DGS-3627:admin#config vlan default delete 1-16 DGS-3627:admin#config vlan 10 add untagged 1-8 DGS-3627:admin#config vlan 20 add untagged 9-16,23</pre>	Create VLAN 10 and 20 and assign relative ports to each VLAN
Step 2	<pre>DGS-3627:admin#create ipif 10 192.168.10.1/24 10 DGS-3627:admin#create ipif 20 192.168.20.1/24 20</pre>	Create two IP interfaces on VLAN 10 and 20
Step 3	<pre>DGS-3627:admin#config ospf router_id 192.168.10.1 DGS-3627:admin#create ospf area 0.0.0.1 type normal DGS-3627:admin#config ospf ipif 10 area 0.0.0.1 state enable DGS-3627:admin#config ospf ipif 20 area 0.0.0.1 state enable DGS-3627:admin#enable ospf</pre>	Enable OSPF on specific interfaces and assign interfaces on area 1.

OSPF Configuration on D-Link Switch - 2

	Command Example	Purpose
Step 1	<pre>DGS-3627:admin#create vlan 40 tag 40 DGS-3627:admin#create vlan 50 tag 50 DGS-3627:admin#config vlan default delete 1-16 DGS-3627:admin#config vlan 40 add untagged 1-8,24 DGS-3627:admin#config vlan 50 add untagged 9-16</pre>	Create VLAN 40 and 50 and assign relative ports to each VLAN
Step 2	<pre>DGS-3627:admin#create ipif 40 192.168.10.1/24 40 DGS-3627:admin#create ipif 50 192.168.20.1/24 50</pre>	Create two IP interfaces on VLAN 40 and 50
Step 3	<pre>DGS-3627:admin#config ospf router_id 192.168.40.1 DGS-3627:admin#create ospf area 0.0.0.2 type normal DGS-3627:admin#config ospf ipif 40 area 0.0.0.2 state enable DGS-3627:admin#config ospf ipif 50 area 0.0.0.2 state enable DGS-3627:admin#enable ospf</pre>	Enable OSPF on specific interfaces and assign interfaces on area 2.

Troubleshooting Examples

Verifying OSPF Information on a Cisco Switch

The following example shows you how to check OSPF detailed information on Cisco Switch. Cisco Switch uses loopback interface to be Router ID and Area 1 should be created.

Command Example

```
Catalyst# show ip ospf
Routing Process "ospf 100" with ID 10.0.0.1
Start time: 00:01:21.528, Time elapsed: 4d19h
Supports only single TOS(TOS0) routes
Supports opaque LSA
Supports Link-local Signaling (LLS)
Supports area transit capability
It is an area border router
Router is not originating router-LSAs with maximum metric
Initial SPF schedule delay 5000 msec
Minimum hold time between two consecutive SPFs 10000 msec
Maximum wait time between two consecutive SPFs 10000 msec
Incremental-SPF disabled
Minimum LSA interval 5 secs
Minimum LSA arrival 1000 msec
LSA group pacing timer 240 secs
Interface flood pacing timer 33 msec
Retransmission pacing timer 66 msec
Number of external LSA 0. Checksum Sum 0x000000
Number of opaque AS LSA 0. Checksum Sum 0x000000
Number of DCbitless external and opaque AS LSA 0
Number of DoNotAge external and opaque AS LSA 0
Number of areas in this router is 2. 2 normal 0 stub 0 nssa
Number of areas transit capable is 0
External flood list length 0
IETF NSF helper support enabled
Cisco NSF helper support enabled
Reference bandwidth unit is 100 mbps
  Area BACKBONE(0)
    Number of interfaces in this area is 1
    Area has no authentication
    SPF algorithm last executed 00:27:19.763 ago
    SPF algorithm executed 14 times
    Area ranges are
    Number of LSA 8. Checksum Sum 0x07E502
    Number of opaque link LSA 0. Checksum Sum 0x000000
    Number of DCbitless LSA 1
    Number of indication LSA 0
    Number of DoNotAge LSA 0
```

```

Flood list length 0
Area 1
Number of interfaces in this area is 1
Area has no authentication
SPF algorithm last executed 00:33:43.525 ago
SPF algorithm executed 8 times
Area ranges are
Number of LSA 6. Checksum Sum 0x036A95
Number of opaque link LSA 0. Checksum Sum 0x000000
Number of DCbitless LSA 1
Number of indication LSA 0
Number of DoNotAge LSA 0
Flood list length 0

```

Checking OSPF Status on D-Link Switch

The following example shows you how to verify if the OSPF is enabled on correct interfaces and if the area assignment is correct.

Command Example

```
switch:admin# show ospf
```

```
Command: show ospf
```

```

OSPF Router ID      : 192.168.10.1
State                : Enabled

```

OSPF Interface Settings

Interface	IP Address	Area ID	State	Link Status	Metric
-----	-----	-----	-----	-----	-----
System	10.90.90.90/8	0.0.0.0	Disabled	Link Up	1
10	192.168.10.1/24	0.0.0.1	Enabled	Link Up	1
20	192.168.20.1/24	0.0.0.1	Enabled	Link Up	1

```
Total Entries : 3
```

OSPF Area Settings

Area ID	Type	Stub Import Summary LSA	Stub Default Cost	Translate
-----	-----	-----	-----	-----
0.0.0.0	Normal	None	None	None
0.0.0.1	Normal	None	None	None

```
Total Entries : 2
```

Virtual Interface Configuration

```

Transit      Virtual      Hello      Dead      Authentication      Link
Area ID      Neighbor Router  Interval   Interval                                     Status
-----
Total Entries : 0

OSPF Area Aggregation Settings

Area ID      Aggregated      LSDB      Advertise
-----
Total Entries : 0

OSPF Host Route Settings

Host Address      Metric      Area ID
-----
Total Entries : 0

```

The following example shows you how to verify if the OSPF interface information is correct.

Command Example

```

switch:admin# show ospf ipif 10
Command: show ospf ipif 10

```

```

Interface Name: 10                                IP Address: 192.168.10.1/24 (Link Up)
Network Medium Type: BROADCAST                     Metric: 1
Area ID: 0.0.0.1                                   Administrative State: Enabled
Priority: 1                                          DR State: DR
DR Address: 192.168.10.1                           Backup DR Address: None
Hello Interval: 10                                Dead Interval: 40
Transmit Delay: 1                                  Retransmit Time: 5
Authentication: None

Passive Mode: Disabled

Total Entries : 1

```

Visit our website for more information
www.dlink.com

D-Link, D-Link logo, D-Link sub brand logos and D-Link product trademarks are trademarks or registered trademarks of D-Link Corporation and its subsidiaries. All other third party marks mentioned herein are trademarks of the respective owners.

Copyright © 2010 D-Link International Pte Ltd. All rights reserved.